

Telescopic Lift Truck

1. Introduction and safety awareness
2. Basic functions of machine (using the telescopic boom)
3. Load assessment /transporting
4. Causes of accidents and accident prevention
5. Steering, lifting, lowering*
6. Correct approach*
7. Stacking de-stacking*
8. Capacity plate. S.W.L. (load centres)
9. Observation / personal safety*
10. Use of controls*
11. Moving off, stopping, safe parking*
12. Hydraulic controls and systems*
13. Use of attachments e.g. Forks, bucket.*
14. Maintenance
15. Negotiating ramps
16. Lorry loading and unloading
17. Fuelling procedures: gas/diesel/petrol/battery)
18. P.P.E.S.
19. Driving skills / operational skills*
20. Regulations / code of practice

* Theory & practical

ALSO BASED AT:

Unit 11, Seaway Parade, Baglan Energy Park, Port Talbot, SA12 7BR Tel No. 01639 822269 Fax No. 01639 822254 e-mail: bts.porttalbot@btconnect.com

Co. Reg. No. 2494292